

Testing Basic Functions:

Check the basic functions in the manual mode. Turn the program selection dial, located under the flip down cover, to “MANUAL”.

OFF:

1. With system switch in the “OFF” position, the thermostat turns off the heating and cooling systems.
2. Setpoints cannot be changed in the “OFF” position.
3. Actual room temperature will continue to be displayed.

Fan:

1. With system switch in the “OFF” position, put the fan switch to the “AUTO” position. The fan should be off.
2. With the system switch in the “OFF” position, put the fan switch to the “ON” position. The fan should run continuously.

