



建議將該《快速指引》放置于屋內較顯眼的位置

對物業房屋有疑問? 請使用網上客戶服務表格 (Customer Service Request Form).

請登入 www.concordpacific.com, 點擊 'Customer Care', 並點選"Homeowner"與對應的專案, 去取得表格.

溫馨提示: 我們只接受業主及租管代理人的客戶服務表格. 若您是租戶, 請與您的房東或租管代理人聯繫反應相關問題。

請即登錄

bchydro.com/moving

電費賬單起始日期為房

屋交付日,有關開戶及

付款各種細則及疑問,請

詳詢 BC Hydro。

Rancho 物業管理公司

物業經理: Joseph Tsang josephtsang@ranchogroup.com

604-331-4253 (直線)

604-684-1956 (傳真)

604-331-4223 (國語)

604-331-4243 (粵語)

緊急聯絡熱線 - 24 小時 604-684-4508

主要負責 The ARC 大樓公共區域的物業 管理工作,例如管理費、購買額外的門禁 遙控、公共設施預訂問題。

關於房屋內的各種裝飾

物料的保養及護理,請 **参照官方網站上的**

HOMEOWNER'S MANUAL

concordpacific.com **CUSTOMER CARE Tab**

Concord Pacific 客戶服務 BC Hydro 開戶

有關房屋內部保養的相關問題,請詢:

Prab Grewal

Email: prab.grewal@concordpacific.com

Phone: 604-899-7232 Fax: 604-899-9183

搬家

請確保您在搬入或搬出前致電您的物業公 司,以預約搬運電梯及作相關安排。

即日起至2019年11月30日預約請聯繫 604-331-4291或 Lle@ranchogroup.com

在2019年12月1日之後,請聯繫服務台 604-786-3842或 thearc@ranchogroup.com

煤氣及水閥總開關

請熟悉您住所的水閥總開關位置, 以便使 用,通常會安裝在您其中一個衣櫃的內 部。煤氣閥門則位於爐灶下方兩側。

如遇緊急情況,請關閉水閥開關以避免不 必要的損失。

長時間的外出

- 當您的住所需要空置長達兩星期以上時,請確保關閉煤氣、冷水及熱水開 關,以避免不必要的麻煩。
- 寒冷天氣中, 建議保持屋內溫度在 17 攝氏度以上。

提示: 當您長期外出時, 建議您邀請您的親屬或朋友幫助打理您的住所, 如 檢查郵箱、保養水槽及坐便器的 U 型下水管(每兩周沖水一次以阻隔異 味)等。

洗衣機/乾衣機



使用普通洗滌劑可能導致下水道堵塞,從 而造成漏水及地板的財產損失。

乾衣提示:請在每次使用乾衣機前,清理 隔離網中的棉絨,以避免火警危險。

大門鎖匙 &門禁遙控

請您試用鎖匙及門禁遙控器, 如需 離開您的住所,建議隨身攜帶門禁 遙控以便您能夠使用電梯及各種通 道等設施。

空氣循環/濕度控制

房屋規範要求您的浴室抽風系統每天 運行至少8小時,以助控制家中的濕 度水平。

预编程的風扇计时器位於洗衣間内, 並設置為兩次,每隔4小時一次。

房屋/租賃保險

為保障住戶利益,我們認為有必要提醒住戶購買房屋/租賃保險.詳見網站住戶指南 --CONCORDPACIFIC.COM - the Homeowner's Manual "Living at The ARC" Section

*業主及住戶都應在搬入前為各自住所的財產及相關責任購買保險。保險細則請詳詢保 險公司經紀人,多謝合作。

窗口開啟角度

切勿 自行更改門窗的開啟角度.

門窗是建築安全規範中一項非常重要 的要求,請勿自行更改.





APPLIANCES /電器概覽

For complete instructions on the operation and care of your appliances, please refer your appliance manuals. It is important to read through all manuals before using the appliances.

All Manuals can be found under the MANUALS tab on your on-line Homeowner's Manual

(Paper copies were left in your Kitchen drawer during your Walk-Through inspection)

Appliance	Model	Contact Info
24" Miele Fridge	KFNS37232iD	
24" Miele Cooktop	KM360GSS	
24" Miele Oven	H2265B	Trail Appliances
Miele Dishwasher	G4998SCVi	604-777-3300
Miele Hoodfan	DA398-7	customercare@trailappliances.com
Panasonic Microwave	NNST775S	<u>castorner care each anapphances.com</u>
Miele Washer	WWF060	Online Request:
Miele Dryer	TWF160	https://www.trailappliances.com/forms/servi
30" Miele Fridge	KFN9855iDERE or KFN9855iDELI	ce-request-form/
30" Miele Cooktop	KM2030GSS	
30" Miele Oven	H6180BPSS	
Miele Coffee Machine	CVA6800SS	
Miele Wine Cooler	KWT1603V	

PAINTED SURFACES /油漆色號

Item #	Area	Color	Paint Code	Sheen	Supplier
1	Walls and Ceilings	BM-CC30 Oxford White	P-1 (03250)	Master Painter Hi-Hide Eggshell	Cloverdale Paint
2	Sills and Baseboards	BM-CC30 Oxford White	P-1A (03250)	Premium Classic Hi- Performance Semi-Gloss	Cloverdale Paint

HARD SURFACES /材料保養

Laminate & Engineered Wood Flooring

A few moments of care and a little common sense can go a long way in keeping your new floors looking their best.

Routine Maintenance:

- Use a damp cloth to blot up spills as soon as they happen as excess water can damage the surface and seep into the seams of the flooring.
- Sweep, dust or vacuum the floor regularly (once or twice a week). Use a broom with soft bristles and/or a vacuum with the hardwood attachment only.
- Periodically clean the floor with cleaning products made specifically for laminate/wood floor care.
- DO NOT wash or wet mop the floor with soap, water, oil-soap, detergent, or any other liquid cleaning material. This could cause swelling, warping, delamination, and joint-line separation, and void the warranty.
- Do not use steel wool, abrasive cleaners, or strong ammoniated or chlorinated type cleaners.
- Do not use any type of buffing or polishing machine.

Environmental Protection:

- Entry mats will help collect the dirt, sand, grit and other substances that might otherwise be tracked onto your floor.
- To prevent slippage of area rugs, use an approved vinyl rug underlayment.
- Use floor protectors and wide-load bearing leg bases/rollers to minimize the chance of indentations and scratches from heavy objects.
- Remember, preferable temperature should be approximately 17-23°C (62-73°F with a relative humidity of 54-60%. Humidity should never be allowed to drop below 30% as this may cause gapping. (Proper humidity levels should be maintained by using your exhaust fan, which has a timer switch on the wall in the closet.)
- Keep your pet's nails trimmed to prevent them from scratching your floor

Marble Tile

Wash with water and a PH neutral cleaner; rinse with warm water and allow drying. Always wipe up spills immediately to prevent staining of the grout.

NOTE: It is the homeowner's responsibility to re-seal the grout with a certified grout sealant. This should be done on an annual basis. You can purchase a grout sealer from your local home improvement store.

Quartz Counters

Quartz countertops are composed of ground quartz stone, pigments, and resin. They are naturally glossy and should not require polishing.

In order to care for your quartz countertops, use non-abrasive cleaners for cleaning. Avoid hard pressure and quick changes in temperature. Do not use metal utensils to remove stuck on material.